TOP AND CABINET PARTS

For Model: 6LBR5132BQ2
(Designer White)

AUTOMATIC WASHER



1	357213	Nut, Push-In
2		Top
	3358226	For White Model
3	62750	Spacer, Cabinet To Top (4)
5		Cabinet
	3350352	For White Model
6	62780	Clip, Top & Cabinet & Rear Panel (2)
8	3356311	Screw & Washer, Lid Switch (2)
11	3949057	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	54583	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19		Lid
	3947509	For White Model
20	358684	Strike, Lid Switch
22	93770	Bumper, Lid (2)
28	384435	Screw, 10-16 x 1/2 (4)
31	90016	Clip, Harness
32	3362952	Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

For Model: 6LBR5132BQ2

(Designer White)



1	16123	Washer, Water Inlet Hose (4) (1-1/16 x 5/8)
3	3358798	Hose, Water Inlet (2)
4	3357027	Nozzle-Drain Hose
5	387402	Hinge, Console (2)
6	3357976	Panel, Rear
7	62747	Pad, Rear Panel
8	661575	Hose, Drain (4'- 8")
	661577	Hose, Drain (9'- 9") (Not Included)
	3357090	Extension, Drain Hose (21 Inches.) (Not Included.)
9	3947639	Timer, Control (60 Hz.) (Motor Not A Service Part)
10	285750	Kit - Adapter (Includes Item 20 and 27)
11	90767	Screw, 8A x 3/8
12	3356468	Switch, Water Level
13	3948814	Bracket, Control
14	3353308	Cord, Power
15	63848	Strain Relief, Power Cord
16		Cap, End (L.H.)
	3358528	For White Model
18	3360393	Valve, Water Mixing
19	90864	Screw, 10-24 x 3/8 (2)
20	3363920	Adapter - Drain Hose
21	370451	Clamp, Hose
	272846	(Alt.)
	353367	(Alt.)
22	62662	Hose, Vacuum Break
23	371503	Clamp, Hose
24	3347034	Break, Vacuum
25	63290	Support, Rear Panel
26	3355497	Connector, Drain Hose
27	356138	Clamp, Hose
28	3359816	Hose, Pump To Drain Connector
30	371502	Clamp, Hose
31	371507	Clamp, Hose
	272858	(Alt.)
	370447	(Alt.)
	353097	(Alt.)
32	62731	Hose, Pump To Tub
35	3348352	Switch, Water Temperature
36	96435	Screw, Timer Mounting (10-32 x 1) (2)
39		Panel, Console
	3363488	For White Model
44	3364291	Knob, Timer
45	3946261	Dial, Timer
47	3358435	Knob, Control
49	388326	Screw, 8-18 (Panel to Top)
50	62863	Screw, 10-16 x 3/8
51		Cap, End (R.H.)
	3358513	For White Model
55	3357331	Clamp, Drain Hose
59	3357011	Screw, 10-16 X 1/2
60	3949113	Harness, Wiring (For Detail See Wiring Harness Parts Page) Also See Clips.

AGITATOR, BASKET AND TUB PARTS

For Model: 6LBR5132BQ2
(Designer White)



1	3355758	Cap, Agitator
2	358237	Screw & Washer (5-16-24 x 1)
4	63235	Agitator
5	3360611	Tub Ring
6	3359586	Gasket, Tub Ring
7	387867	Clip, Balance Ring (8)
8	387868	Balance Ring
9	3361948	Plate - Filter
12	21366	Nut, Spanner
13	8274449	Basket
14	63039	Tub (Includes Item 18)
15	389140	Block, Basket Drive
16	383727	Gasket, Centerpost
17	3347780	Hose, Pressure Switch
18	3948705	Hose, Bleach

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: 6LBR5132BQ2
(Designer White)



1	388951	Brake & Drive Tube (Complete) (Refer to Brake & Drive Tube Parts Page for Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3351343	Clutch (Complete)
6	3946793	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3363337	Spring, Clutch
9	3949118	Gearcase (Complete) (Refer To Gearcase Parts Page For Further Breakdown.)
10	3357334	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	3364003	Coupling, Motor And Isolation Coupling
14	3946532	Shield, Motor
16	3357334	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	3363190	Motor, Main Drive
20	62850	Switch, Main Drive Motor
21	62700	Retainer, Pump (2)
22	3363892	Pump (Complete)
25	3387485	Screw (2) 10-16 x 5/8
26	3355454	Clip, Anti-Rattle
27	62863	Screw, 10-16 x 5/16
28	357021	Capacitor
29	357030	Clamp, Capacitor

MACHINE BASE PARTS

For Model: 6LBR5132BQ2

(Designer White)



1	343641	Screw, Bracket Mounting (10-16 x 1/2)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring (3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	3348725	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3349337	Base Assembly (Includes Illus, 6, 7, 8, 9, 16, 17, 18 & 26)
21	62739	Nut, Lock (3/8-16) (2)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

WIRING HARNESS PARTS

For Model: 6LBR5132BQ2

(Designer White)



WH2E

1	3349557	Clip, Harness
2	388498	Clip, Harness
3	3347812	Clip, Harness
4	3352501	Clip, Harness
5	90016	Clip, Harness
6	3390496	Clip, Harness
7	389379	Retainer, (Suds Models)
8	352090	Timer, Block Disconnect (White)
9	352089	Timer, Block Disconnect (Black)
10	62889	Receptacle, Terminal (3-Way) (Lid Switch) (Use Term 94613 Or 94614)
11	353424	Plug, Terminal (3-Way) (Power Cord) (Use Term 94613)
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term 352088)
13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614)
14	3347243	Block, Disconnect (Use Term. 352088)
15	63523	Protector
16	717252	Connector (2-Way) (Use Term. 94614)
17	387566	Plug, Terminal (4-Way) (Power Cord) (Use M3 Screws)
18	3352944	Clip, Harness
19	3390423	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)
20	3347730	Receptacle (6-Way) (Use Term. 94613)
21	388818	Plug, Terminal (12-Way) (Use Term. 94613 Or 94614)
22	3369366	Timer, Block Disconnect (Black) (Amp) (Use Term 3369365)
23	3349494	Connector, Etc
24	60687	Connector, Relay (Use Term. 308569 Or 338664)
25	3407125	E.T.C. Control
26	3948617	Connector (T.P.A.) (3-Circuit) (Lid Switch)
27	3360056	Connector (T.P.A) (3-Circuit) (Pressure Switch)
28	3354925	Block, Connector (Cold Valve)
29	3354926	Block, Connector (Hot Valve)
30	3948615	Connector (T.P.A.) (6-Circuit) (Temp. Switch)

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

BRAKE AND DRIVE TUBE PARTS

For Model: 6LBR5132BQ2

(Designer White)



1	388951	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Brake Shoe
9	62703	``T'' Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	62647	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

	285208	Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin) (Designer White)

GEARCASE PARTS

For Model: 6LBR5132BQ2
(Designer White)



GC–217

1	3363361	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring (2)
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 & 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 & 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust (Includes 18)
18	85529	Ball, Bearing (Includes 17)
19	3366851	Bottom and Pinion Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	3348567	Gear, Spin
26	285595	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

WATER SYSTEM PARTS

For Model: 6LBR5132BQ2
(Designer White)



WS400

1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

MISCELLANEOUS PARTS

For Model: 6LBR5132BQ2
(Designer White)



1	3946908	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (1-1/16 x 5/8) (4)
4	62739	Nut, Lock (2) (3/8-16)
5	389102	Foot, Front (2)
7	356138	Clamp, Hose

LITERATURE PARTS

	LIT3948875	Sheet, Installation Instructions
	LIT3363835	Guide, Use and Care
	LIT3364214	Energy Guide
	LIT3947642	Label, Wiring Diagram
	LIT881356	List, Repair Parts

Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS

	LIT4313896	Manual, (Washer) Do-It-Yourself

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	72107	Almond
	72110	Golden Harvest

PAINT, PRESSURIZED SPRAY (13 oz.)

	350938	Primer, Gray
	350930	White
	350956	Almond
	261890	Golden Harvest

PAINT, BULK (1 qt.)

	799344	White (Uncut)
	978883	Almond (Uncut)
	261891	Golden Harvest (Uncut)

OIL

	350572	Oil, Gearcase (16 Oz.)

LUBRICANT

	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)

SHIPPING KIT

	3348675	Shipping Kit

ACCESSORY PARTS

	89121	Stand-Pipe Kit
	367031	Drain Protector
	285320	Siphon Break Kit